

VIVO<sup>2</sup>  
*By Ted Brewer*

**OWNERS MANUAL**

# CONTENTS

1. Fitting the Battery
2. Connecting the Violin
3. Turning the Violin on
4. Turning the Violin off
5. Adjusting the volume
6. Adjusting the Tone
7. Tuning the Violin
8. Using Sound to Light function
9. Low Battery indicator
10. Care of your Instrument

## 1. Fitting the Battery

Your Vivo2 Violin is designed to be powered by its onboard 9v Alkaline Battery. Fitting is simple – invert the violin, unscrew the thumb screw which secures the battery cover plate. Remove the plate, fit the battery to the connection lead, checking the polarity. Gently push the battery into the body of the violin, taking care not to trap any wires. Refit the battery cover and tighten the thumb screw (finger tight only).



Initially after installing the battery for the first time, both banks of lights may illuminate fully, touch the volume down button until the bank reduces and do the same with the tone button.


PLEASE NOTE WE RECOMMEND THE USE OF ALKALINE BATTERIES.

## 2. Connecting the Vivo2

The Vivo2 is fitted with a standard ¼" jack socket that will allow connection to an amplifier using readily available leads. Please be sure to follow the amplifier manufacturers guidelines and safety advice when connecting to their equipment. You will find the touch controls on the Vivo2 more effective if you connect a connection lead or set of headphones to the instrument.

## 3. Turning the Violin on

Once the battery is fitted the Vivo2 can be turned on simply by touching the volume up button for 2 seconds. The two banks of ultra bright leds will illuminate briefly to indicate it is turned on.



## 4. Turning the Violin off

The Vivo2 has the inbuilt function of turning itself off if it detects the instrument has not been used for approximately 3 minutes, thus saving battery power automatically.

Touching the volume up button for 2 seconds will bring the Vivo2 back to life.

If the Vivo2 is to be stored or not used for a long period of time – it is recommended to remove the battery from the instrument.

## 5. Adjusting the Volume

The two forward touch buttons are the volume controls.

Touch the top button to increase volume.




Touch the bottom button to decrease volume.

LED lights will illuminate to show the desired level and the processor will retain these settings even with the battery disconnected.

## 6. Adjusting the Tone

The two rear buttons control the tone.

Touch the top button to increase the tone.




Touch the bottom button to decrease the tone.

LED lights will illuminate to show the desired level and the processor will retain these settings even with the battery disconnected.

## Tuning the Vivo2

The Vivo2 is fitted with high quality grover machine heads and has fine tuners for each string, thus making tuning easy.


Also when the Vivo2 is connected to an amplifier or headphones, an audible 'A' tone can be generated for a few seconds by touching the two tone buttons at the same time for a few seconds. This allows for accurate tuning of the 'A' String.



During this tone the two top LEDs will illuminate.

## Using the Sound to Light function

The Vivo2 has two vertical banks of bright white LEDs. These are able to be switched to flash in time to the intensity of your playing.



To activate or deactivate the Sound to Light facility, with the violin turned on, touch the two volume buttons at the same time. Both bank of LEDs will illuminate briefly.

## Low Battery indicator

Situated under the bridge is a green LED. This is a built in battery level indicator that is illuminate whenever any of the user functions are activated. This gives a visual warning of low battery. If the LED changes from Green to Red – it is recommended that the battery is replaced at the owners earliest convenience. When the LED changes from Green to Red all lighting displays for all functions are automatically cancelled. This conserves power for the audio function, allowing for several more hours playing.

## Care of the Vivo2

The Vivo2 violin can be cleaned with a soft cloth and a gentle antistatic cleaner. Abrasive cleaners and solvents must not be used as these could damage the Vivo2.